SUN2000-30/36/40KTL-M3 Smart PV Controller







Smart

8 strings intelligent monitoring



Efficient Max. efficiency 98.7%





Fuse free design

Safe




Reliable Type II surge arresters for DC & AC





SUN2000-30/36/40KTL-M3 Technical Specification

	Efficiency		
Max. Efficiency	98.7%		
European Efficiency	98.4%		
		Increase	
Mana Jamash Malda ang 1		Input	
Max. Input Voltage ¹		1,100 V	
Max. Current per MPPT	26 A		
Max. Short Circuit Current per MPPT Start Voltage	40 A 200 V		
MPPT Operating Voltage Range ²		200 V ~ 1000 V	
Rated Input Voltage		600 V	
Number of Inputs		8	
Number of MPP Trackers		4	
		Output	
Rated AC Active Power	30,000 W	36,000 W	40,000 W
Max. AC Apparent Power	33,000 VA ³	40,000 VA	44,000 VA
Rated Output Voltage	2	30 Vac / 400 Vac / 480 Vac, 3W/N+P	E
Rated AC Grid Frequency		50 Hz / 60 Hz	
Rated Output Current	43.3 A	52.0 A	57.8 A
Max. Output Current	47.9 A	58.0 A	63.8 A
Adjustable Power Factor Range		0.8 LG 0.8 LD	
Max. Total Harmonic Distortion		< 3%	
		Protection	
nput-side Disconnection Device		Yes	
Anti-islanding Protection		Yes	
AC Overcurrent Protection		Yes	
OC Reverse-polarity Protection		Yes	
PV-array String Fault Monitoring		Yes	
DC Surge Arrester		Yes	
AC Surge Arrester		Yes	
DC Insulation Resistance Detection		Yes	
Residual Current Monitoring Unit		Yes	
Arc Fault Protection		Yes	
Ripple Receiver Control Integrated PID Recovery ⁴		Yes	
		105	
		Communication	
Display	LED Indicators, Integrated WLAN + FusionSolar APP		
RS485	Yes WLAN/Ethernet via Smart Dongle-WLAN-FE (Optional)		
Smart Dongle		5	1 7
Monitoring BUS (MBUS)	4G / 3G / 2G via Smart Dongle-4G (Optional) Yes (Isolation Transformer required)		
		Care I Dat	
		General Data	n ela)
Dimensions (W x H x D) Weight (with mounting plate)	640	x 530 x 270 mm (25.2 x 20.9 x 10.6 i	ncn)
Operating Temperature Range		43 kg (94.8 lb) -25 ~ + 60 °C (-13 °F ~ 140 °F)	
Cooling Method		Natural Convection	
Max. Operating Altitude		0 - 4,000 m (13,123 ft.)	
		0% RH ~ 100% RH	
Relative Humidity		Staubli MC4	
	W	aterproof Connector + OT/DT Termir	nal
DC Connector	Waterproof Connector + OT/DT Terminal IP 66		
DC Connector			
DC Connector AC Connector Protection Degree		Transformerless	
DC Connector AC Connector Protection Degree Fopology		Transformerless ≤ 5.5W	
DC Connector AC Connector Protection Degree Fopology		≤ 5.5W	
DC Connector AC Connector Protection Degree Fopology Vightime Power Consumption		≤ 5.5W Optimizer Compatibility	/
DC Connector AC Connector Protection Degree Fopology Vightime Power Consumption		≤ 5.5W Optimizer Compatibility SUN2000-450W-P	
DC Connector AC Connector Protection Degree Fopology Nightime Power Consumption DC MBUS Compatible Optimizer	Standard Com	≤ 5.5W Optimizer Compatibility SUN2000-450W-P pliance (more available	upon request)
Relative Humidity DC Connector AC Connector Protection Degree Topology Nightime Power Consumption DC MBUS Compatible Optimizer	Standard Com	≤ 5.5W Optimizer Compatibility SUN2000-450W-P pliance (more available 62109-1/-2, EN 50530, IEC 62116, IE	upon request) C 60068, IEC 61683



SUN2000-(20KTL, 29.9KTL, 30KTL, 36KTL, 40KTL)-M3

User Manual

lssue 03 Date 2021-04-15



HUAWEI TECHNOLOGIES CO., LTD.

Copyright © Huawei Technologies Co., Ltd. 2021. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

NUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base Bantian, Longgang Shenzhen 518129 People's Republic of China

Website: <u>https://e.huawei.com</u>

About this Document

Overview

This document describes the SUN2000-20KTL-M3, SUN2000-29.9KTL-M3, SUN2000-30KTL-M3, SUN2000-36KTL-M3, and SUN2000-40KTL-M3 (SUN2000 for short) in terms of their installation, electrical connections, commissioning, maintenance, and troubleshooting. Before installing and operating the SUN2000, ensure that you are familiar with the features, functions, and safety precautions provided in this document.

Intended Audience

This document is applicable to:

- Installers
- Users

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Remarks
	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

Symbol	Remarks
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.
☐ NOTE	Supplements the important information in the main text. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

Change History

Changes between document issues are cumulative. The latest document issue contains all changes made in earlier issues.0

Issue 03 (2021-04-15)

Updated 2.1 Overview.

Updated 5.2 Preparing Cables.

Updated 5.5 Installing the DC Input Power Cable.

Added 7.1.3 (Optional) Setting the Physical Layout of the Smart PV Optimizers.

Added 7.1.4 Detect optimizer disconnection.

Updated 10 Technical Specifications.

Issue 02 (2020-11-20)

Updated 2.3 Label Description.

Updated 4.3 Selecting an Installation Position.

Updated 5.2 Preparing Cables.

Updated 5.7.1 Communication Modes.

Updated 10 Technical Specifications.

Issue 01 (2020-10-15)

This issue is the first official release.

Contents

About this Document	ii
1 Safety Information	1
1.1 General Safety	1
1.2 Personnel Requirements	2
1.3 Electrical Safety	3
1.4 Installation Environment Requirements	4
1.5 Mechanical Safety	4
1.6 Commissioning	5
1.7 Maintenance and Replacement	6
2 Overview	7
2.1 Overview	7
2.2 Appearance	9
2.3 Label Description	
2.4 Working Principles	
2.4.1 Circuit Diagram	13
2.4.2 Working Modes	
3 SUN2000 Storage	
	15
3 SUN2000 Storage	15 16
3 SUN2000 Storage	15 16 .16
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation	15 16
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation	15 16
 3 SUN2000 Storage 4 Installation	15 16 161718
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000	15 16 16171822
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000 4.5 Installing the Mounting Bracket	15 16 161718
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000 4.5 Installing the Mounting Bracket 4.5.1 Support-mounted Installation	15 16 161718222222
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000 4.5 Installing the Mounting Bracket 4.5.1 Support-mounted Installation 4.5.2 Wall-mounted Installation	15 16 16171822232425
3 SUN2000 Storage	15 16 1617182222222324242528
3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000 4.5 Installing the Mounting Bracket 4.5.1 Support-mounted Installation 4.5.2 Wall-mounted Installation 4.6 Installing a SUN2000 5 Electrical Connections	
 3 SUN2000 Storage 4 Installation 4.1 Checking Before Installation 4.2 Tool Preparation 4.3 Selecting an Installation Position 4.4 Moving the SUN2000 4.5 Installing the Mounting Bracket. 4.5.1 Support-mounted Installation 4.5.2 Wall-mounted Installation 4.6 Installing a SUN2000 5 Electrical Connections. 5.1 Precautions 	

5.5 Installing the DC Input Power Cable5.6 (Optional) Installing the Smart Dongle	
5.7 Connecting the Signal Cable	40
5.7.1 Communication Modes	43
5.7.2 (Optional) Connecting the RS485 Communications Cable to the SUN2000	44
5.7.3 (Optional) Connecting the RS485 Communications Cable to the Power Meter	45
5.7.4 (Optional) Connecting the Power Grid Scheduling Signal Cable	46
5.7.5 (Optional) Connecting the Rapid Shutdown Signal Cable	47
6 Commissioning	49
6.1 Checking Before Power-On	
6.2 System Power-On	50
7 Man-Machine Interaction	52
7.1 Scenario in Which SUN2000s Are Connected to the FusionSolar Smart PV Management System	
7.1.1 (Optional) Registering an Installer Account	
7.1.2 Creating a PV Plant and a User	54
7.1.3 (Optional) Setting the Physical Layout of the Smart PV Optimizers	
7.1.4 Detect optimizer disconnection	57
7.1.5 SmartLogger Networking Scenario	57
7.2 Scenario in Which SUN2000s Are Connected to Other Management Systems	58
8 Maintenance	59
8.1 System Power-Off	59
8.2 Routine Maintenance	60
8.3 Troubleshooting	60
9 Handling the Inverter	71
9.1 Removing the SUN2000	71
9.2 Packing the SUN2000	71
9.3 Disposing of the SUN2000	71
10 Technical Specifications	72
A Grid Code	77
B Device Commissioning	80
C Setting Power Adjustment Parameters	. 83
D Built-in PID Recovery	84
E Rapid Shutdown	86
F Resetting Password	87
G Setting Dry Contact Scheduling Parameters	88
H AFCI	89
I Smart I-V Curve Diagnosis	92

Acronyms and Abbreviations93

Safety Information

1.1 General Safety

Statement

Before installing, operating, and maintaining the equipment, read this document and observe all the safety instructions on the equipment and in this document.

The "NOTICE", "CAUTION", "WARNING", and "DANGER" statements in this document do not cover all the safety instructions. They are only supplements to the safety instructions. Huawei will not be liable for any consequence caused by the violation of general safety requirements or design, production, and usage safety standards.

Ensure that the equipment is used in environments that meet its design specifications. Otherwise, the equipment may become faulty, and the resulting equipment malfunction, component damage, personal injuries, or property damage are not covered under the warranty.

Follow local laws and regulations when installing, operating, or maintaining the equipment. The safety instructions in this document are only supplements to local laws and regulations.

Huawei will not be liable for any consequences of the following circumstances:

- Operation beyond the conditions specified in this document
- Installation or use in environments which are not specified in relevant international or national standards
- Unauthorized modifications to the product or software code or removal of the product
- Failure to follow the operation instructions and safety precautions on the product and in this document
- Equipment damage due to force majeure, such as earthquakes, fire, and storms
- Damage caused during transportation by the customer
- Storage conditions that do not meet the requirements specified in this document

General Requirements

A DANGER

Do not work with power on during installation.

- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, and performing outdoor installation) in harsh weather conditions such as lightning, rain, snow, and level 6 or stronger wind.
- After installing the equipment, remove idle packing materials such as cartons, foam, plastics, and cable ties from the equipment area.
- In the case of a fire, immediately leave the building or the equipment area, and turn on the fire alarm bell or make an emergency call. Do not enter the building on fire in any case.
- Do not scrawl, damage, or block any warning label on the equipment.
- Tighten the screws to the specified torque using tools when installing the equipment.
- Understand the components and functioning of a grid-tied PV power system and relevant local standards.
- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches cannot be exposed to an outdoor environment for a long period of time.
- Do not open the host panel of the equipment.

Personal Safety

- If there is a probability of personal injury or equipment damage during operations on the equipment, immediately stop the operations, report the case to the supervisor, and take feasible protective measures.
- Use tools correctly to avoid hurting people or damaging the equipment.
- Do not touch the energized equipment, as the enclosure is hot.

1.2 Personnel Requirements

- Personnel who plan to install or maintain Huawei equipment must receive thorough training, understand all necessary safety precautions, and be able to correctly perform all operations.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will operate the equipment, including operators, trained personnel, and professionals, should possess the local national required qualifications in special operations such as high-voltage operations, working at heights, and operations of special equipment.

• Only professionals or authorized personnel are allowed to replace the equipment or components (including software).

NOTE

- Professionals: personnel who are trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, and maintenance
- Trained personnel: personnel who are technically trained, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Operators: operation personnel who may come in contact with the equipment, except trained personnel and professionals

1.3 Electrical Safety

Grounding

- For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.
- Do not damage the ground conductor.
- Do not operate the equipment in the absence of a properly installed ground conductor.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is securely grounded.

General Requirements

🚹 DANGER

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

- Ensure that all electrical connections comply with local electrical standards.
- Obtain approval from the local electric utility company before using the equipment in grid-tied mode.
- Ensure that the cables you prepared meet local regulations.
- Use dedicated insulated tools when performing high-voltage operations.

AC and DC Power

1 DANGER

Do not connect or disconnect power cables with power on. Transient contact between the core of the power cable and the conductor will generate electric arcs or sparks, which may cause fire or personal injury.

- Before making electrical connections, switch off the disconnector on the upstream device to cut off the power supply if people may contact energized components.
- Before connecting a power cable, check that the label on the power cable is correct.
- If the equipment has multiple inputs, disconnect all the inputs before operating the equipment.

Cabling

- When routing cables, ensure that a distance of at least 30 mm exists between the cables and heat-generating components or areas. This prevents damage to the insulation layer of the cables.
- Bind cables of the same type together. When routing cables of different types, ensure that they are at least 30 mm away from each other.
- Ensure that the cables used in a grid-tied PV power system are properly connected and insulated and meet specifications.


1.4 Installation Environment Requirements

- Ensure that the equipment is installed in a well ventilated environment.
- To prevent fire due to high temperature, ensure that the ventilation vents or heat dissipation system are not blocked when the equipment is running.
- Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

1.5 Mechanical Safety

Using Ladders

- Use wooden or fiberglass ladders when you need to perform live working at heights.
- When a step ladder is used, ensure that the pull ropes are secured and the ladder is held firm.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the wider end of the ladder is at the bottom, or protective measures have been taken at the bottom to prevent the ladder from sliding.
- Ensure that the ladder is securely positioned. The recommended angle for a ladder against the floor is 75 degrees, as shown in the following figure. An angle rule can be used to measure the angle.



- When climbing a ladder, take the following precautions to reduce risks and ensure safety:
 - Keep your body steady.
 - Do not climb higher than the fourth rung of the ladder from the top.
 - Ensure that your body's center of gravity does not shift outside the legs of the ladder.


Drilling Holes

When drilling holes into a wall or floor, observe the following safety precautions:

- Wear goggles and protective gloves when drilling holes.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings that have accumulated inside or outside the equipment.

Moving Heavy Objects

• Be cautious to avoid injury when moving heavy objects.



• When moving the equipment by hand, wear protective gloves to prevent injuries.

1.6 Commissioning

When the equipment is powered on for the first time, ensure that professional personnel set parameters correctly. Incorrect settings may result in inconsistency with local certification and affect the normal operation of the equipment.

1.7 Maintenance and Replacement

▲ DANGER

High voltage generated by the equipment during operation may cause an electric shock, which could result in death, serious injury, or serious property damage. Prior to maintenance, power off the equipment and strictly comply with the safety precautions in this document and relevant documents.

- Maintain the equipment with sufficient knowledge of this document and using proper tools and testing equipment.
- Before maintaining the equipment, power it off and follow the instructions on the delayed discharge label to ensure that the equipment is powered off.
- Place temporary warning signs or erect fences to prevent unauthorized access to the maintenance site.
- If the equipment is faulty, contact your dealer.
- The equipment can be powered on only after all faults are rectified. Failing to do so may escalate faults or damage the equipment.

2_{Overview}

2.1 Overview

Function

The SUN2000 inverter is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.

Model

This document covers the following SUN2000 models:

- SUN2000-20KTL-M3
- SUN2000-29.9KTL-M3
- SUN2000-30KTL-M3
- SUN2000-36KTL-M3
- SUN2000-40KTL-M3

NOTE

The SUN2000-20KTL-M3 supports 220 V (line voltage) power grids.

Figure 2-1 Model description (SUN2000-30KTL-M3 is used as an example)

SUI	N2000-	30k	(TL-	М3
		ļ		
I		2	3	4

ID	Meaning	Value
1	Series name	SUN2000: three-phase grid-tied PV string inverter


ID	Meaning	Value	
2	Power class	• 20K: rated power of 20 kW	
		• 29.9K: rated power of 29.9 kW	
		 30K: rated power of 30 kW 	
		• 36K: rated power of 36 kW	
		• 40K: rated power of 40 kW	
3	Тороlоду	TL: transformerless	
4	Product code	M3: product series with an input voltage level of 1100 V DC ^a	

Note a: The maximum DC input voltage of SUN2000-20KTL-M3 is 800 V. For details, see **10 Technical Specifications**.

Networking Application

The SUN2000 applies to the grid-tied systems of industrial and commercial rooftops and small ground PV plants. Typically, a grid-tied system consists of PV strings, grid-tied inverters, AC switches, and power distribution units.


Figure 2-2 Networking application - single inverter scenario




Supported Power Grid Types


The SUN2000 supports TN-S, TN-C, TN-C-S, TT, and IT power grids.

Figure 2-3 Power grid types



2.2 Appearance






- (1) LED indicator
- (3) Heat sink
- (5) Communications port (COM)
- (7) DC switch (DC SWITCH)
- (9) Ventilation valve
- (11) AC output port

- (2) Front panel
- (4) Screws for fixing the awning
- (6) Hole for the DC switch locking screw
- (8) Smart Dongle port (4G/WLAN-FE)
- (10) DC input terminals (PV1-PV8)
- (12) Ground point

2.3 Label Description

Nameplate

Figure 2-5 Nameplate



- (1) Trademark and product model
- (3) Label information

(2) Key technical parameters

(4) Company name and country of origin

The nameplate figure is for reference only.

Enclosure Labels

Symbol	Name	Description
Danger: High Voltage! 高圧危險! Start maintaining the INVERTER at least 5 minutes after the INVERTER disconnects from all external power supplies. 近空器与外部所有电源断开后,需要等待至少5分钟,才可以进行维护。	Delay discharge	Residual voltage exists after the SUN2000 is powered off. It takes 5 minutes for the SUN2000 to discharge to the safe voltage.
Warning: High Temperature! 高温危险 Never touch the enclosure of an operating INVERTER. 逆变器工作时严禁触摸外壳。	Burn warning	Do not touch a running SUN2000 because it generates high temperatures on the shell.
Danger: Electrical Hazardl有电危险! Only certified professionals are allowed to install and operate the INVERTER. 仅有资质的专业人员才可进行 逆变器的安装和操作。 High touch current, earth connection essential before connecting supply. 大接触电流! 接通电源前须先接地。	Electric shock warning	 High voltage exists after the SUN2000 is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the SUN2000. High touch current exists after the SUN2000 is powered on. Before powering on the SUN2000, ensure that the SUN2000 is properly grounded.
CAUTION Read instructions carefully before performing any operation on the INVERTER. 对逆变器进行任何操作前,请 仔细阅读说明书 !	Refer to documentation	Reminds operators to refer to the documents delivered with the SUN2000.
	Grounding label	Indicates the position for connecting the PE cable.
Do not disconnect under load! 禁止带负荷断开连接!	Operation warning	Do not remove the DC input connector or AC output connector with power on.

Symbol	Name	Description
▲ 32-55 kg (70-121 lbs)	Weight label	The SUN2000 is heavy and needs to be carried by three persons.
CAUTION Do not touch the handles within 10 minutes after the inverter is shut down! Não toque pelo menos 10 minutos após o inversor ser desligado ! 关机10分钟后才能触碰 !	Burn warning on inverter handles	Do not touch the handles within 10 minutes after the inverter is shut down.
通行指示 Running indication 工 La 1 La 1 La 2 Maaning La 1 La 2 Maaning La 1 La 2 Maaning Staady green Staady green Staady green Staady green Altong intervana Altong intervana Altong intervana Statisting green Statisting green </td <td>Indicator</td> <td>Indicates the SUN2000 operating information.</td>	Indicator	Indicates the SUN2000 operating information.
(1P)PN/ITEM:XXXXXXXX (32P)Model:SUN2000-XXXTL-XX (S)SN-XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	SUN2000 serial number	Indicates the serial number.
WLAN SSID: SUN2000-XXXXXXXXX Password:XXXXXXXX C	SUN2000 WiFi login QR code	Scan the QR code to connect to the Huawei SUN2000 WiFi network.

2.4 Working Principles

2.4.1 Circuit Diagram

A SUN2000 can connect to a maximum of eight PV strings and has four MPPT circuits inside. Each MPPT circuit tracks the maximum power point of two PV strings. The SUN2000 converts DC power into single-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.




Figure 2-6 Schematic diagram

2.4.2 Working Modes

The SUN2000 can work in Standby, Operating, or Shutdown mode.




Figure 2-7 Working modes

IS07S00001

Table 2-2 Working mode description

Working Mode	Description
Standby	The SUN2000 enters Standby mode when the external environment does not meet the operating requirements. In Standby mode:
	• The SUN2000 continuously performs status check and enters the Operating mode once the operating requirements are met.
	 The SUN2000 enters Shutdown mode after detecting a shutdown command or a fault after startup.
Operating	In Operating mode:
	• The SUN2000 converts DC power from PV strings into AC power and feeds the power to the power grid.
	• The SUN2000 tracks the maximum power point to maximize the PV string output.
	 If the SUN2000 detects a fault or a shutdown command, it enters the Shutdown mode.
	• The SUN2000 enters Standby mode after detecting that the PV string output power is not suitable for connecting to the power grid for generating power.
Shutdown	 In Standby or Operating mode, the SUN2000 enters Shutdown mode after detecting a fault or shutdown command.
	• In Shutdown mode, the SUN2000 enters Standby mode after detecting a startup command or that the fault is rectified.

3 SUN2000 Storage

The following requirements should be met if the SUN2000 is not put into use directly:

- Do not unpack the SUN2000.
- Keep the storage temperature at -40°C to +70°C and the humidity at 5%– 95% RH.
- Store the SUN2000 in a clean and dry place and protect it from dust and water vapor corrosion.
- A maximum of six SUN2000s can be stacked. To avoid personal injury or device damage, stack SUN2000s with caution to prevent them from falling over.
- During the storage period, check the SUN2000 periodically (recommended: every three months). If any rodent bites are found on the packing materials, replace the packing materials immediately.
- If the SUN2000 has been stored for more than two years, it must be checked and tested by professionals before being put into use.

4 Installation

4.1 Checking Before Installation

Outer Packing Materials

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.

Package Contents

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

NOTE

For details about the number of contents, see the *Packing List* in the packing case.

4.2 Tool Preparation

Туре	Tools and Instruments				
Install ation					
	Hammer drill (with a Φ14 mm drill bit and a Φ16 mm drill bit)	Torque socket and wrench	Torque wrench		
	Diagonal pliers	Wire stripper	Torque screwdriver		
	Rubber mallet	Utility knife	Cable cutter		
	A CONTRACT OF A	2 <u>00;</u> e	0		
	Crimping tool (model: PV-CZM-22100)	Open-end wrench (model: PV-MS-HZ or PV-MS open- end wrench)	Cable tie		
			₫		
	Vacuum cleaner	Multimeter (DC voltage measurement range ≥ 1100 V DC)	Marker		

Туре	Tools and Instruments				
		<u>A-QQ</u>			
	Steel measuring tape	Level	Hydraulic pliers		
			-		
	Heat shrink tubing	Heat gun			
Person al protec tive equip ment (PPE)					
	Safety gloves	Safety goggles	Anti-dust mask		
	Centres Contraction	-	-		
	Safety boots				

4.3 Selecting an Installation Position

Basic Requirements

- The SUN2000 is IP66-rated and can be installed indoors or outdoors.
- Do not install the SUN2000 in a place where a person can easily be exposed to its enclosure and heat sinks, because these parts are extremely hot during operation.
- Do not install the SUN2000 in areas with flammable or explosive materials.
- Do not install the SUN2000 in a place within children's reach.
- The SUN2000 will be corroded in salt areas, and the salt corrosion may cause fire. Do not install the SUN2000 outdoors in salt areas. A salt area refers to the region within 500 m from the coast or prone to sea breeze. The effect from sea breeze depends on weather conditions (such as typhoon and season wind) or terrains (such as dams and hills).

Site Requirements

- The SUN2000 should be installed in a well-ventilated environment to ensure good heat dissipation.
- If the SUN2000 is installed in a place exposed to direct sunlight, the power may decrease as the temperature rises.
- You are advised to install the SUN2000 in a sheltered place or install an awning over it.

Mounting Structure Requirements


- The mounting structure where the SUN2000 is installed must be fire resistant.
- Do not install the SUN2000 on flammable building materials.
- The SUN2000 is heavy. Ensure that the installation surface is solid enough to bear the weight load.
- In residential areas, do not install the SUN2000 on drywalls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the SUN2000 is noticeable.

Installation Angle Requirements

The SUN2000 can be wall-mounted or support-mounted. Requirements for the installation angle:


- Install the SUN2000 vertically or at a maximum back tilt of 15 degrees to facilitate heat dissipation.
- Do not install the SUN2000 with a front tilt, excessive back tilt, side tilt, horizontally, or upside down.

Figure 4-1 Installation angle




Installation Space Requirements

• Reserve enough clearance around the SUN2000 to ensure sufficient space for installation and heat dissipation.




• When installing multiple SUN2000s, install them in horizontal mode if ample space is available and install them in triangle mode if no ample space is available. Stacked installation is not recommended.

Figure 4-3 Horizontal installation (recommended)













Figure 4-5 Three-layer triangle installation (not recommended)









D NOTE

The installation diagrams are for reference only and are irrelevant to the SUN2000 cascading scenario.


4.4 Moving the SUN2000

Procedure

Step 1 Lift the SUN2000 from the packing case and move it to the specified installation position.

- Move the SUN2000 with care to prevent device damage and personal injury.
- Do not use the wiring terminals and ports at the bottom to support any weight of the SUN2000.
- Place a foam pad or cardboard under the SUN2000 to protect the SUN2000 enclosure from damage.

Figure 4-8 Moving the SUN2000




----End

4.5 Installing the Mounting Bracket

Installation Precautions

Before installing the mounting bracket, remove the security Torx wrench and set it aside.





(1) Security Torx wrench

Figure 4-10 shows the dimensions of the mounting holes for the SUN2000.




Figure 4-10 Mounting bracket dimensions

4.5.1 Support-mounted Installation

Procedure

Step 1 Secure the mounting bracket.




Figure 4-11 Securing the mounting bracket

NOTE

You are advised to apply anti-rust paint on the hole positions for protection.

----End

4.5.2 Wall-mounted Installation

Prerequisites

To install the SUN2000, you need to prepare expansion bolts. M12x60 stainless steel expansion bolts are recommended.


Procedure

- **Step 1** Determine the positions for drilling holes and mark the positions using a marker.
- **Step 2** Secure the mounting bracket.

A DANGER

Avoid drilling holes in the water pipes and cables buried in the wall.

Figure 4-12 Expansion bolt composition




- (1) Bolt (2) Nut (3) Spring washer
- (4) Flat washer (5) Expansion sleeve

NOTICE

- To prevent dust inhalation or contact with eyes, wear safety goggles and an anti-dust mask when drilling holes.
- Clean up any dust in and around the holes using a vacuum cleaner and measure the distance between holes. If the holes are inaccurately positioned, drill holes again.
- Level the front of the expansion sleeve with the concrete wall after removing the bolt, spring washer, and flat washer. Otherwise, the mounting bracket will not be securely installed on the concrete wall.

Figure 4-13 Installing expansion bolts




----End


4.6 Installing a SUN2000

Step 1 (Optional) Install the locking screw for the DC switch.


NOTE

- The DC switch locking screw is used to lock the DC switch to prevent the switch from rotating.
- For models used in Australia, install the DC switch locking screw according to local standards. The DC switch locking screw is delivered with the SUN2000.






Step 2 Install the SUN2000 onto the mounting bracket.



Step 3 Tighten the nuts on both sides of the SUN2000.

Figure 4-16 Tightening the nut



NOTICE

Secure the screws on the sides before connecting cables.

----End

5 Electrical Connections

5.1 Precautions

When exposed to sunlight, the PV arrays supply DC voltage to the SUN2000. Before connecting cables, ensure that the two DC switches on the SUN2000 are OFF. Otherwise, the high voltage of the SUN2000 may result in electric shocks.

- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electrician can perform electrical terminations.
- Wear proper PPE at all time when terminating cables.
- To prevent poor cable connection due to overstress, it is recommended that the cables be bent and reserved, and then connected to the appropriate ports.

NOTE

The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for grounding).

5.2 Preparing Cables

Figure 5-1 SUN2000 cable connections (dashed boxes indicate optional components)




Table 5-1 Components

No.	Componen t	Description	Source
A	PV string	 A PV string consists of PV modules connected in series. 	Prepared by users
		• The SUN2000 supports the input from eight PV strings.	
В	AC switch	 Recommended: a three-phase AC circuit breaker with a rated voltage greater than or equal to 500 V AC and a rated current of: 63 A (SUN2000-29.9KTL/30KTL-M3) 80 A (SUN2000-20KTL-M3) 100 A (SUN2000-36KTL/40KTL-M3) 	Prepared by users
С	Power meter	The SUN2000 can connect to the DTSU666-H power meter.	Prepared by users

No.	Componen t	Description	Source
		The following third-party power meters are supported:	
		ABB-A44, Schneider-PM1200, Janitza-UMG604, Janitza-UMG103- CBM, Janitza-UMG104, GAVAZZI- EM340-DIN AV2 3 X S1 X, REAL ENERGY SYSTEM-PRISMA-310A, Algodue-UPM209, Mitsubishi- LMS-0441E, and WEG-MMW03- M22CH	
		When the WEG-MMW03-M22CH power meter is connected, set Baud rate to 9600 .When the Mitsubishi- LMS-0441E power meter is connected, set Parity mode to No parity , and Baud rate to 9600 .	
D	SUN2000	Select a proper model as required.	Purchased from Huawei
E	SmartLogg er	The SmartLogger1000A, SmartLogger2000, and SmartLogger3000 are supported.	Purchased from Huawei
F	Environmen tal monitoring instrument (EMI)	 When the SmartLogger is used, the EMI can be directly connected to the SmartLogger or connected to the last solar inverter cascaded over RS485. 	Prepared by by users
		• When the SDongle is used, the EMI is a cascaded device that needs to be connected to the solar inverter where the SDongle is installed. In this case, only the EMI with the baud rate of 9600 is supported.	
G	Smart Dongle	Select a proper model as required.	Purchased from Huawei
Н	(Optional) Smart PV optimizer	The SUN2000-450W-P smart PV optimizer is supported.	Purchased from Huawei

NOTE

In the SUN2000 cascading scenario, the master inverter model can be SUN2000-20KTL/29.9KTL/ 30KTL/36KTL/40KTL-M3, and the slave inverter model can be SUN2000-(3KTL-12KTL)-M0/M1, SUN2000-(12KTL-20KTL)-M0/M2, SUN2000-50KTL/60KTL/65KTL-M0, SUN2000-(100KTL, 110KTL, 125KTL) series, SUN2000-29.9KTL/36KTL/42KTL, or SUN2000-33KTL-A.

NOTICE

The cable specifications must comply with local standards.

No.	Cable	Туре	Recommended Specifications	Source
1	DC input power cable	Common PV cable in the industry (Recommended model: PV1-F)	 Conductor cross- sectional area: 4–6 mm² Cable outer diameter: 5.5–9 mm 	Prepare d by users
2	AC output power cable	Outdoor copper-core/ aluminum-core cable	 Conductor cross- sectional area: 16-50 mm² outdoor copper- core cable or 35-50 mm² outdoor aluminum-core cable Cable outer diameter: 16–38 	Prepare d by users
3	(Option al) Signal cable	Two-core outdoor shielded twisted pair (recommended model: DJYP2VP2-2x2x0.75)	 Conductor cross- sectional area: 0.2- 1 mm² Cable outer diameter: 4-11 mm 	Prepare d by users
4	PE cable	Single-core outdoor copper-core cable	Conductor cross- sectional area ≥ 16 mm ²	Prepare d by users
	: Five-core c are not suppo	ables with a cross-sectional orted.	area of 5 x 35 mm ² or 5	x 50

If the SUN2000 is used with an optimizer, route the AC and DC power cables separate to avoid interference to the communication of the optimizer.

5.3 Connecting the PE Cable

1 DANGER

- Ensure that the PE cable is securely connected. Otherwise, electric shocks may occur.
- Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.

D NOTE

- The PE point at the AC output port is used only as a PE equipotential point, not a substitute for the PE point on the enclosure.
- It is recommended that silicone sealant or paint be applied around the ground terminal after the PE cable is connected.

Procedure

Step 1 Crimp OT terminals.

NOTICE

- Avoid scratching the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT terminal is crimped must wrap the core wires completely. The core wires must contact the OT terminal closely.
- Wrap the wire crimping area with heat shrink tubing or PVC insulation tape. The heat shrink tubing is used as an example.
- When using a heat gun, protect devices from being scorched.






Figure 5-2 Crimping an OT terminal



Step 2 Connect the PE cable.

Figure 5-3 Connecting the PE cable



(1) Standby protection ground point

5.4 Connecting the AC Output Power Cable

Precautions

An AC switch must be installed on the AC side of the SUN2000 to ensure that the SUN2000 can be safely disconnected from the power grid.

Do not connect loads between the SUN2000 and the AC switch.


NOTICE

- Use a socket wrench and extension rod to connect the AC power cable. The extension rod must be longer than 100 mm.
- Sufficient slack should be provided in the PE cable to ensure that the last cable bearing the force is the PE cable when the AC output power cable bears pulling force due to force majeure.
- Do not install third-party devices in the AC connection box.
- You need to prepare M8 OT terminals by yourself.

Procedure

Step 1 Remove the AC terminal box and install partition boards.

Figure 5-4 Removing the AC terminal box



Step 2 Connect the AC output power cable (using a five-core cable as an example).

NOTE

- To avoid damaging the rubber liner, do not route a cable with a crimped OT terminal directly through it.
- It is recommended that the length of the PE cable to be stripped be 15 mm longer than the length of other cables.
- The cable colors in figures are for reference only. Select appropriate cables according to the local standards.

Figure 5-5 Stripping the AC power cable





Figure 5-6 Connecting the AC power cable



5.5 Installing the DC Input Power Cable

Precautions


- Before connecting the DC input power cables, ensure that the DC voltage is within the safe range (lower than 60 V DC) and that the DC switch on the SUN2000 is OFF. Failing to do so may result in electric shocks.
- When the SUN2000 is running, it is not allowed to work on the DC input power cables, such as connecting or disconnecting a PV string or a PV module in a PV string. Failing to do so may cause electric shocks.
- If no PV string connects to a DC input terminal of the SUN2000, do not remove the watertight cap from the DC input terminals. Otherwise, the IP rating of the SUN2000 will be affected.

Ensure that the following conditions are met. Otherwise, the SUN2000 may be damaged, or even a fire could happen.

- PV modules connected in series in each PV string are of the same specifications.
- The DC input voltage of the SUN2000-29.9KTL/30KTL/36KTL/40KTL-M3 shall not exceed 1100 V DC under any circumstance.
- The DC input voltage of the SUN2000-20KTL-M3 shall not exceed 800 V DC under any circumstance.
- The polarities of electric connections are correct on the DC input side. The positive and negative terminals of a PV string connect to corresponding positive and negative DC input terminals of the SUN2000.
- If polarity of the DC input power cable is reversed and the DC switch is ON, do not turn off the DC switch immediately or remove positive and negative connectors. Wait until the solar irradiance declines at night and the PV string current reduces to below 0.5 A, and then turn off the DC switch and remove the positive and negative connectors. Correct the PV string polarity before reconnecting the PV string to the SUN2000.

- The SUN2000 does not support power supplies other than PV strings. Since the output of the PV string connected to the SUN2000 cannot be grounded, ensure that the PV module output is well insulated to ground.
- During the installation of PV strings and the SUN2000, the positive or negative terminals of PV strings may be short-circuited to ground if the power cable is not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the SUN2000. The caused device damage is not covered under any warranty.

Figure 5-7 DC input terminals



When the DC input is not fully configured, the DC input terminals must meet the following requirements:

1. Distribute the DC input power cables evenly over four MPPT circuits, and connect them preferentially through MPPT1 and MPPT4.

Number of PV Strings	Terminal Selection	Number of PV Strings	Terminal Selection
1	PV1	2	PV1 and PV7
3	PV1, PV3 and PV7	4	PV1, PV3, PV5 and PV7
5	PV1, PV2, PV3, PV5 and PV7	6	PV1, PV2, PV3, PV5, PV7 and PV8
7	PV1, PV2, PV3, PV4, PV5, PV7 and PV8	8	PV1, PV2, PV3, PV4, PV5, PV6, PV7 and PV8

2. Maximize the number of connected MPPT circuits.

Procedure

Step 1 Connect the DC power cable.

Use the positive and negative Staubli MC4 metal terminals and DC connectors supplied with the SUN2000. Using incompatible positive and negative metal terminals and DC connectors may result in serious consequences. The caused device damage is not covered under warranty.

- You are advised to use the PV-CZM-22100 (Staubli) crimping tool and do not use it with the positioning block. Otherwise, the metal terminals may be damaged.
- The PV-MS (Staubli) or PV-MS-HZ (Staubli) open-end wrench is recommended.
- Cables with high rigidity, such as armored cables, are not recommended as DC input power cables, because poor contact may be caused by the bending of the cables.
- Before assembling DC connectors, label the cable polarities correctly to ensure correct cable connections.
- After the positive and negative connectors snap into place, pull the DC input cables back to ensure that they are connected securely.
- If the SUN2000 is used with an optimizer, the number of optimizers for a single PV string cannot exceed 26.
- If the PV string is configured with an optimizer, check the cable polarity by referring to the smart PV optimizer quick guide.




Figure 5-8 Connecting the DC power cable

----End


5.6 (Optional) Installing the Smart Dongle


Procedure

The Smart Dongle is not provided in standard configuration.

4G Smart Dongle

- If your Smart Dongle is not equipped with a SIM card, prepare a standard SIM card (size: 25 mm x 15 mm) with the capacity greater than or equal to 64 KB.
- When installing the SIM card, determine its installation direction based on the silk screen and arrow on the card slot.
- Press the SIM card in place to lock it, indicating that the SIM card is correctly installed.
- When removing the SIM card, push it inwards to eject it.
- When reinstalling the cover of the Smart Dongle, ensure that the buckle springs back in place.





• WLAN-FE Smart Dongle (WLAN Communication)

Figure 5-10 Installing a WLAN-FE Smart Dongle (WLAN communication)



WLAN-FE Smart Dongle (FE Communication)




Figure 5-11 Installing a WLAN-FE Smart Dongle (FE communication)

NOTICE

Install the network cable before installing the Smart Dongle on the solar inverter.

NOTE

 For details about how to operate the WLAN-FE Smart Dongle SDongleA-05, see *SDongleA-05 Quick Guide (WLAN-FE)*. You can scan the QR code below to obtain the document.



 For details about how to operate the 4G Smart Dongle SDongleA-03, see *SDongleA-03 Quick Guide (4G)*. You can scan the QR code below to obtain the document.




The quick guide is delivered with the Smart Dongle.

5.7 Connecting the Signal Cable

COM Port Pin Definitions

NOTICE

When laying out a signal cable, separate it from power cables to avoid strong signal interference.



Pin	Definitio n	Function	Description	Pin	Definitio n	Function	Description
1	485A1_1	RS485 differential signal +	cascade inverters or connect to the	2	485A1_2	RS485 differential signal +	Used to cascade inverters or
3	485B1_1	RS485 differential signal –		4	485B1_2	RS485 differential signal –	connect to the SmartLogger. It can also connect to an EMI.
5	PE	Ground point on the shield layer	-	6	PE	Ground point on the shield layer	-
7	485A2	RS485 differential signal +	Connects to the RS485 signal port for	8	DIN1	Dry contact for power grid	-
9	485B2	RS485 differential signal –	controlling the power meter at the grid-tied point.	10	DIN2	scheduling	
11	-	-	-	12	DIN3		
13	GND	GND	-	14	DIN4		

Pin	Definitio n	Function	Description	Pin	Definitio n	Function	Description
15	DIN5	Rapid shutdown	Supports AC NS protection shutdown, which can be used as a reserved port for rapid shutdown signals.	16	GND		

Scenarios Where No Signal Cable Is Connected

NOTICE

If no signal cable is required for the SUN2000, use waterproof plugs to block the wiring holes on the signal cable connector and connect the signal cable connector to the communications port on the SUN2000 to improve the waterproof performance of the SUN2000.





Figure 5-13 Securing the signal cable connector

5.7.1 Communication Modes

RS485 Communication

• Smart Dongle networking

Figure 5-14 Smart Dongle networking




D NOTE

If a SUN2000 is networked using a Smart Dongle, it cannot be connected to the SmartLogger.

SmartLogger networking

Figure 5-15 SmartLogger networking



NOTE


- If a SUN2000 is networked using the SmartLogger, it cannot be connected to a Smart Dongle.
- It is recommended that the number of SUN2000s connected to each RS485 route be less than 30.

MBUS Communication

The MBUS is a communication mode in which communication signals are loaded to power cables through the communications board for transmission.


D NOTE


The built-in MBUS module in the SUN2000 does not need to be connected with cables.




5.7.2 (Optional) Connecting the RS485 Communications Cable to the SUN2000

Procedure







Issue 03 (2021-04-15)

Step 2 Connect the signal cable connector to the COM port.




Figure 5-18 Securing the signal cable connector

----End

5.7.3 (Optional) Connecting the RS485 Communications Cable to the Power Meter

Procedure

Step 1 Connect the signal cable to the signal cable connector.




Figure 5-19 Connecting the cable

IS10I20008

Step 2 Connect the signal cable connector to the COM port.





Figure 5-20 Securing the signal cable connector

5.7.4 (Optional) Connecting the Power Grid Scheduling Signal Cable

Procedure

Step 1 Connect the signal cable to the signal cable connector.

Figure 5-21 Connecting the cable



Step 2 Connect the signal cable connector to the COM port.




Figure 5-22 Securing the signal cable connector

5.7.5 (Optional) Connecting the Rapid Shutdown Signal Cable

Step 1 Connect the signal cable to the signal cable connector.






Figure 5-23 Connecting the cable

13131400

Step 2 Connect the signal cable connector to the COM port.





6 Commissioning

6.1 Checking Before Power-On

Table 6-1 Checklist

No.	Check Item	Acceptance Criteria
1	SUN2000 installation	The SUN2000 is installed correctly and securely.
2	Smart Dongle	The Smart Dongle is installed correctly and securely.
3	Cable routing	The cables are routed properly as required by the customer.
4	Cable ties	Cable ties are evenly distributed and no burr exists.
5	Reliable grounding	The PE cable is connected correctly and securely.
6	Switch	DC switches and all the switches connecting to the SUN2000 are OFF.
7	Cable connection	The AC output power cable, and DC input power cables are connected correctly and securely.
8	Unused terminals and ports	Unused terminals and ports are locked by watertight caps.
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy.

6.2 System Power-On

Prerequisites


NOTICE

- Before turning on the AC switch between the SUN2000 and the power grid, check that the AC voltage is within the specified range using a multimeter.
- If the DC power supply is connected but the AC power supply is disconnected, the SUN2000 will report a **Grid Loss** alarm. The SUN2000 can start properly only after the power grid recovers.

Procedure

- **Step 1** Turn on the AC switch between the SUN2000 and the power grid.
- **Step 2** (Optional) Remove the locking screw beside the DC switch.

Figure 6-1 Removing the locking screw beside the DC switch



Step 3 Turn on the DC switch at the bottom of the SUN2000.

Step 4 Observe the LED indicators to check the operating status of the SUN2000.

 Table 6-2 Indicator description

Category	Status	Description	
Running	LED1	LED2	-
indicator ≡[]~ (ආ) ○ ○ ○	Steady green	Steady green	The SUN2000 is operating in grid-tied mode.
LED1 LED2	Blinking green slowly (on for 1s and off for 1s)	Off	The DC is on and the AC is off.

Category	Status		Description
	Blinking green slowly (on for 1s and off for 1s)	Blinking green slowly (on for 1s and off for 1s)	Both the DC and AC are on, and the SUN2000 is not supplying power to the power grid.
	Off	Blinking green slowly	The DC is off and the AC is on.
	Off	Off	Both the DC and AC are off.
	Blinking red fast (on for 0.2s and off for 0.2s)	-	DC environment alarm
	-	Blinking red fast (on for 0.2s and off for 0.2s)	AC environment alarm
	Steady red	Steady red	Faulty
Communications	LED3		_
indicator ■]~ (m) ○ ○ ○ LED3	Blinking green fast then off for 0.2s)	Communication is in progress.	
	Blinking green slow for 1s)	A mobile phone is connected.	
	Off	No communication	
Note: If LED1, LED to be replaced.	02, and LED3 are stea	dy red, the SUN2000	is faulty and needs

Man-Machine Interaction

D NOTE

- If the SUN2000 is connected to the FusionSolar Smart PV Management System, the FusionSolar app is recommended. In areas (such as the UK) where the FusionSolar app is not available, or when a third-party management system is used, only the SUN2000 app can be used for commissioning.
- Access the Huawei app store (http://appstore.huawei.com), search for FusionSolar or SUN2000, and download the app installation package. You can also scan the QR codes below to download the apps.



NOTICE

- The screenshots are for reference only. The actual screens may vary.
- Obtain the initial password for connecting to the solar inverter WLAN from the label on the side of the solar inverter.
- Set the password at the first login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- Set the correct grid code based on the application area and scenario of the SUN2000.

7.1 Scenario in Which SUN2000s Are Connected to the FusionSolar Smart PV Management System

7.1.1 (Optional) Registering an Installer Account

NOTE

The installer can be registered using a mobile number (only in China) or an email address. The two registration modes are automatically switched based on the server settings.

Step 1 Run the FusionSolar app. If no account and password are created, tap No account, select I'm an installer, and enter the registration information.




Figure 7-1 Registering an account

7.1.2 Creating a PV Plant and a User




Figure 7-2 Creating a PV plant and a user

For details about how to use the site deployment wizard, see *FusionSolar App Quick Guide*. During the FusionSolar app upgrade, scan the QR code to download the corresponding quick guide according to the downloaded app version.




7.1.3 (Optional) Setting the Physical Layout of the Smart PV Optimizers

- If smart PV optimizers are configured for PV strings, ensure that the smart PV optimizers have been successfully connected to the SUN2000 before performing the operations in this section.
- Check that the SN labels of smart PV optimizers are correctly attached to the physical layout template.
- Take and save a photo of the physical layout template. Keep your phone parallel to the template and take a photo in landscape mode. Ensure that the four positioning points in the corners are in the frame. Ensure that each QR code is attached within the frame.
- For details about the physical layout of smart PV optimizers, see *FusionSolar App Quick Guide*. During the FusionSolar app upgrade, scan the QR code to download the corresponding quick guide according to the downloaded app version.



Scenario 1: Setting on the FusionSolar Server Side (Solar Inverter Connected to the Management System)

Step 1 Log in to the FusionSolar app and tap the plant name on the Home screen to



407-GJC-TEST 👯 Setup wizard 2. Add user 24°C Logical layou 02/20/2021 Q 407-GJC-TEST 0.00 kW/ 6 lin 10.00 kWp 0.00 kWh 🖹 10 kWh m 出 C 08 Ð Ð × ⊕ C 12


Figure 7-3 Uploading the physical layout template photo (App)

NOTE

You can also upload the physical layout template photo on the WebUI as follows: Log in to https://intl.fusionsolar.huawei.com to access the WebUI of the FusionSolar Smart PV Management System. On the home page, click the plant name to go to the plant page.


Choose Layout, click , and upload the physical layout template photo.

Figure 7-4 Uploading the physical layout template photo (WebUI)



Step 2 Log in to https://intl.fusionsolar.huawei.com to access the WebUI of the FusionSolar Smart PV Management System. On the Home page, click the plant name to go to the plant page. Select Layout. Choose Generate Layout, and create a physical layout as prompted. You can also manually create a physical location layout.

Figure 7-5 Physical layout design of PV modules



----End

Scenario 2: Setting on the Solar Inverter Side (Solar Inverter Not Connected to the Management System)

- **Step 1** Access the **B Device Commissioning** screen on the FusionSolar app to set the physical layout of Smart PV Optimizers.
 - Log in to the FusionSolar app. On the Device Commissioning screen, choose Maintenance > Optimizer layout. The Optimizer layout screen is displayed.
 - 2. Tap the blank area. The **Identify image** and **Add PV modules** buttons are displayed. You can use either of the following methods to perform operations as prompted:
 - Method 1: Tap Identify image and upload the physical layout template photo to complete the optimizer layout. (The optimizers that fail to be identified need to be manually bound.)

 Method 2: Tap Add PV modules to manually add PV modules and bind the optimizers to the PV modules.

< Maintenance		<	Optimizer layout	Submit	<	Optimizer layout	Submit
(+) Add/Delete device	>	Output power	(W) • Physical	layout *	Outpu	power(W) • Physical	layout *
Optimizer yout Physical lag	>		3	5.		3	5
(1) Upgrade d	>			Ň		Add PV modules	N N
D Log management	>		n			Identify image	
(1) Performance data	>			?		· · · · · · · · · · · · · · · · · · ·	?
Optimizer disconnection detection	>						

7.1.4 Detect optimizer disconnection

Log in to the FusionSolar app, choose **Device Commissioning** > **Maintenance** > **Optimizer disconnection detection**, tap the detection button to detect the optimizer disconnection, and rectify the fault based on the detection result.

Figure 7-7 Detect optimizer disconnection

K Maintenance		Contimizer disconnection				
+ Add/Delete device	>	If the fault is rectified, perform diagnosis again to confirm.				
Optimizer layout Physical layout design of PV modules	>	Optimizer disconnection detection	Ð			
1 Upgrade device	>					
Log management	>			_		
H Performance data	>			4		disconnection ection
Optimizer disconnection detection	>	if the fault is reclified, perform diagnosis agan to confirm. Optimizer disconnection	0		If the fault is rectified, perfo confirm. Optimizer disconnec detection	
④ AFCI self-check		detection			Getection	_
Inverter ON/OFF Standby : insulation resistance detection		Detecting	53	7		Tips ant to perform optimized tion detection?
Restore defaults		-	-	- 1		
Clear alarms				- 1	Cancel	Confirm
Clear historical energy yield						

7.1.5 SmartLogger Networking Scenario

For details, see *PV Plants Connecting to Huawei Hosting Cloud Quick Guide* (*Inverters + SmartLogger3000*), *PV Plants Connecting to SmartPVMS Quick Guide* (*Inverters + SmartLogger3000 + RS485 Networking*) and *PV Plants Connecting to SmartPVMS Quick Guide* (*Inverters + SmartLogger3000 + MBUS Networking*).

⁻⁻⁻⁻End

7.2 Scenario in Which SUN2000s Are Connected to Other Management Systems

- **Step 1** Open the SUN2000 app, scan the QR code of the SUN2000 or manually connect to the WLAN hotspot to access the device commissioning screen.
- **Step 2** Select **installer** and enter the login password.
- **Step 3** Tap **Log in** to access the quick settings screen or SUN2000 home screen.

	< Identity authentication	< Quick settings	< SUN2000-XXX
		Device detection Completed	Active power Energy yield of current day
	175	Setting basic Connect to mpmt syst parameters	0.000,000,000,000,000,000,000,000,000,0
8		Grid code	Monthly Energy Vield Total 8.19940 146.90aae
		Voltage level	Q R
		Grid frequency	Alarm Quick settings
		Phone time	
Connection record See more	SN:XXXXXXXXX	Phone time zone UTC+08:00	₽
	This and karmonid	Sync phone time	Device Monitoring Maintenance
SUN2000-XXXKTL-XX Connectable			@ III
	Cancel Log in	Next	Settings Power adjustment

Figure 7-8 Logging In to the app

8 Maintenance

8.1 System Power-Off


Precautions

After the SUN2000 powers off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and begin operating the SUN2000 five minutes after the power-off.

Procedure

- **Step 1** Send a shutdown command on the app.
- **Step 2** Turn off the AC switch between the SUN2000 and the power grid.
- **Step 3** Turn off the DC switch at the bottom of the SUN2000.
- **Step 4** (Optional) Install the locking screw for the DC switch.

Figure 8-1 Installing the locking screw for the DC switch



Step 5 Turn on the DC switch between the PV string and the SUN2000 if there is any.

8.2 Routine Maintenance

To ensure that the SUN2000 can operate properly for a long term, you are advised to perform routine maintenance on it as described in this chapter.

Before cleaning the system, connecting cables, and ensuring the grounding reliability, power off the system.

Check Item	Check Method	Maintenance Interval	
System cleanliness	Check periodically that the heat sinks are free from obstacles and dust.	Once every 6 to 12 months	
System operating status	 Check that the SUN2000 is not damaged or deformed. Check that the SUN2000 operates with no abnormal sound. Check that all SUN2000 parameters are correctly set during operation. 	Once every 6 months	
Electrical connection	 Check that cables are secured. Check that cables are intact, and that in particular, the parts touching the metallic surface are not scratched. 	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.	
Grounding reliability	Check that ground cables are securely connected.	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.	
Air tightness	Check that all terminals and ports are properly sealed.	Once a year	

Table 8-1 Maintenance checklist

8.3 Troubleshooting

Alarm severities are defined as follows:

- Major: The inverter is faulty. As a result, the output power decreases or the grid-tied power generation is stopped.
- Minor: Some components are faulty without affecting the grid-tied power generation.
- Warning: The inverter works properly. The output power decreases or some authorization functions fail due to external factors.

ID	Name	Severity	Cause	Solution
2001	High string input voltage	Major	 The PV array is not properly configured. Excessive PV modules are connected in series to the PV string, and therefore the PV string open-circuit voltage exceeds the maximum inverter operating voltage. Cause ID 1: PV strings 1 and 2 Cause ID 2: PV strings 3 and 4 Cause ID 3: PV strings 5 and 6 Cause ID 4: PV strings 7 and 8 	Reduce the number of PV modules connected in series to the PV string until the PV string open-circuit voltage is less than or equal to the maximum inverter operating voltage. After the PV string configuration is corrected, the alarm disappears.
2002	DC arc fault	Major	 The PV string power cables arc or are in poor contact. Cause ID 1: PV strings 1 and 2 Cause ID 2: PV strings 3 and 4 Cause ID 3: PV strings 5 and 6 Cause ID 4: PV strings 7 and 8 	Check whether the PV string cables arc or are in poor contact.
2003	DC arc fault	Major	The PV string power cables arc or are in poor contact. Cause ID 1–8: PV strings 1– 8	Check whether the PV string cables arc or are in poor contact.

 Table 8-2
 Common fault alarm list

ID	Name	Severity	Cause	Solution
2011	String reverse connecti on	Major	The PV string polarity is reversed. Cause ID 1–8: PV strings 1– 8	Check whether the PV string is reversely connected to the inverter. If yes, wait until the solar irradiance declines at night and the PV string current drops to below 0.5 A. Then, turn off the two DC switches and correct the PV string connection.
2012	String current backfeed	Warning	The number of PV modules connected in series to the PV string is insufficient. As a result, the terminal voltage is lower than that of other strings. Cause ID 1–8: PV strings 1– 8	 Check whether the number of PV modules connected in series to the PV string is less than that of other PV strings. If yes, wait until the PV string current drops below 0.5 A, turn off all DC switches, and adjust the number of PV modules in the PV string. Check whether the open- circuit voltage of the PV string is abnormal. Check whether the PV string is shaded.
2021	AFCI self- check failure	Major	Cause ID = 1, 2 The AFCI self-check fails.	Turn off the AC output switch and DC input switch, and then turn them on after 5 minutes. If the alarm persists, contact Huawei technical support.
2031	Phase wire short- circuited to PE	Major	Cause ID = 1 The impedance of the output phase wire to PE is low or the output phase wire is short-circuited to PE.	Check the impedance of the output phase wire to PE, locate the position with low impedance, and rectify the fault.
2032	Grid loss	Major	 Cause ID = 1 Power grid outage occurs. The AC circuit is disconnected or the AC switch is off. 	 The alarm is cleared automatically after the power grid recovers. Check whether the AC circuit is disconnected or the AC switch is off.

ID	Name	Severity	Cause	Solution
2033	Grid undervol tage	Major	Cause ID = 1 The power grid voltage is below the lower threshold or the low-voltage duration has lasted for more than the value specified by LVRT.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal. If the alarm persists, check whether the power grid voltage is within the acceptable range. If not, contact the local power operator. If yes, modify the grid undervoltage protection threshold through the app, SmartLogger, or NMS with the consent of the local power operator. If the alarm persists for a long time, check the AC circuit breaker and AC output power cable.
2034	Grid overvolt age	Major	Cause ID = 1 The power grid voltage exceeds the upper threshold or the high voltage duration has lasted for more than the value specified by HVRT.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal. If the alarm persists, check whether the power grid frequency is within the acceptable range. If not, contact the local power operator. If yes, modify the grid overfrequency protection threshold through the app, SmartLogger, or NMS with the consent of the local power operator. Check whether the peak voltage of the power grid is too high. If the alarm persists and lasts for a long time, contact the local power operator.

ID	Name	Severity	Cause	Solution
2035	Grid volt. Imbalan ce	Major	Cause ID = 1 The difference between power grid phase voltages exceeds the upper threshold.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal.
				2. If the alarm persists, check whether the power grid voltage is within the acceptable range. If not, contact the local power operator.
				 If the alarm lasts for a long time, check the AC output power cable connection.
				4. If the AC output power cable is correctly connected, yet the alarm persists and affects the energy yield of the PV plant, contact the local power operator.
2036	Grid overfreq uency	Major	Cause ID = 1 Power grid exception: The actual power grid frequency is higher than the requirements for the local power grid code.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal.
				2. If the alarm persists, check whether the power grid frequency is within the acceptable range. If not, contact the local power operator. If yes, modify the grid overfrequency protection threshold through the app, SmartLogger, or NMS with the consent of the local power operator.

ID	Name	Severity	Cause	Solution
2037	Grid underfre quency	Major	Cause ID = 1 Power grid exception: The actual power grid frequency is lower than the requirements for the local power grid code.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal. If the alarm persists, check whether the power grid frequency is within the acceptable range. If not, contact the local power operator. If yes, modify the grid underfrequency protection threshold through the app, SmartLogger, or NMS with the consent of the local power operator.
2038	Unstable grid frequenc y	Major	Cause ID = 1 Power grid exception: The actual change rate of the power grid frequency does not meet the requirements for the local power grid code.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The inverter automatically recovers after detecting that the power grid becomes normal. If the alarm persists, check whether the power grid frequency is within the acceptable range. If not, contact the local power operator.
2039	Output overcurr ent	Major	Cause ID = 1 The power grid voltage drops dramatically or the power grid is short- circuited. As a result, the inverter transient output current exceeds the upper threshold, and protection is triggered.	 The inverter monitors its external operating conditions in real time and automatically recovers after the fault is rectified. If the alarm persists and affects the energy yield of the PV plant, check whether the output is short-circuited. If the fault cannot be rectified, contact your dealer or Huawei technical support.

ID	Name	Severity	Cause	Solution
2040	Output DC compon ent overhigh	Major	Cause ID = 1 The DC component of the inverter output current exceeds the upper threshold.	 The inverter monitors its external operating conditions in real time and automatically recovers after the fault is rectified. If the alarm persists and affects the energy yield of the PV plant, contact your dealer or Huawei technical support.
2051	Abnorm al residual current	Major	Cause ID = 1 The insulation impedance of the input side to PE decreases when the inverter is operating.	 If the alarm occurs accidentally, the external power cable may be abnormal temporarily. The inverter automatically recovers after the fault is rectified. If the alarm persists or lasts a long time, check whether the impedance between the PV string and ground is too low.
2061	Abnorm al groundin g	Major	 Cause ID = 1 The neutral wire or PE cable of the inverter is not connected. The output mode set for the inverter is inconsistent with the cable connection mode. 	 Power off the inverter (turn off the AC output switch and DC input switch, and wait for a period of time. For details about the wait time, see the description on the device safety warning label), and then perform the following operations: 1. Check whether the PE cable for the inverter is connected properly. 2. If the inverter is connected to a TN power grid, check whether the neutral wire is properly connected and whether the voltage of the neutral wire to ground is normal. 3. After the inverter is powered on, check whether the output mode set for the inverter is consistent with the output cable connection mode.

ID	Name	Severity	Cause	Solution	
2062	Low insulatio n resistanc e	Major	 Cause ID = 1 The PV array is short-circuited with PE. The PV string has been in a moist environment for a long time and the circuit is not well insulated to ground. 	 Check the impedance between the PV string and the PE cable. If a short circuit occurs, rectify the fault. Check whether the PE cable of the inverter is correctly connected. If you have confirmed that the impedance is lower than the specified protection threshold in a cloudy or rainy environment, log in to the app, SmartLogger, or NMS and set Insulation resistance protection threshold. 	
2063	Cabinet overtem perature	Minor	 Cause ID = 1 The inverter is installed in a place with poor ventilation. The ambient temperature exceeds the upper threshold. The inverter is not operating properly. 	 Check the ventilation and ambient temperature at the inverter installation position. If the ventilation is poor or the ambient temperature exceeds the upper threshold, improve the ventilation and heat dissipation. If both the ventilation and ambient temperature meet requirements yet the alarm persists, contact your dealer or Huawei technical support. 	
2064	Device fault	Major	Cause ID = 1–15 An unrecoverable fault occurs on a circuit inside the inverter.	Turn off the AC output switch and DC input switch, and then turn them on after 5 minutes. If the alarm persists, contact your dealer or Huawei technical support. NOTICE Cause ID = 1: Perform the preceding operations when the PV string current is less than 1 A.	
2065	Upgrade failed or version mismatc h	Minor	Cause ID = 1–6 The upgrade is not completed normally.	 Perform an upgrade again. If the upgrade fails several times, contact your dealer or Huawei technical support. 	

ID	Name	Severity	Cause	Solution
2066	License expired	Warning	 Cause ID = 1 The privilege license has entered the grace period. The privilege feature is about to expire. 	 Apply for a new license. Load a new certificate.
2067	Faulty power collector	Major	Cause ID = 1 The power meter is disconnected.	 Check whether the configured power meter model is the same as the actual model. Check whether the communications parameters of the power meter are the same as the RS485 configurations of the inverter. Check whether the power meter is powered on and whether the RS485 communications cable is connected.
61440	Faulty monitori ng unit	Minor	 Cause ID = 1 The flash memory is insufficient. The flash memory has bad sectors. 	Turn off the AC output switch and DC input switch, and then turn them on after 5 minutes. If the alarm persists, replace the monitoring board or contact your dealer or Huawei technical support.
2072	Transient AC overvolt age	Major	Cause ID = 1 The inverter detects that the phase voltage exceeds the transient AC overvoltage protection threshold.	 If the voltage at the grid connection point is too high, contact the local power operator. If you have confirmed that the voltage at the grid connection point exceeds the upper threshold and obtained consent from the local power operator, modify the overvoltage protection thresholds. Check whether the peak grid voltage exceeds the upper threshold.

ID	Name	Severity	Cause	Solution
2085	Built-in PID operatio n abnorma l	Minor	 Cause ID = 1, 2 The output resistance of PV arrays to ground is low. The system insulation resistance is low. 	 Cause ID = 1 1. Turn off the AC output switch and DC input switch, wait for a period of time (for details about the wait time, see the description on the device safety warning label), and then turn on the DC input switch and AC output switch. If the alarm persists, contact your dealer or Huawei technical support. Cause ID = 2 Check the impedance between the PV array output and the ground. If a short circuit occurs or the insulation is insufficient, rectify the fault. If the alarm persists, contact your dealer or Huawei technical support.
2090	Abnorm al active power scheduli ng instructi on	Major	 Cause ID = 1 The DI input is abnormal. The DI input is inconsistent with the configuration. 	 Check whether the cables are connected correctly to the DI ports. On the DI active scheduling screen under the dry contact scheduling settings, view the DI signal configuration mapping table. Contact the power grid company to check whether the configurations in the mapping table are complete and meet the requirements.

ID	Name	Severity	Cause	Solution
2091	Abnorm al reactive power scheduli ng instructi on	Major	 Cause ID = 1 The DI input is abnormal. The DI input is inconsistent with the configuration. 	 Check whether the cables are connected correctly to the DI ports. On the DI reactive power scheduling screen under the dry contact scheduling settings, view the DI signal configuration mapping table. Contact the power grid company to check whether the configurations in the mapping table are complete and meet the requirements.

NOTE

Contact your dealer or Huawei technical support if all troubleshooting procedures listed above are completed and the fault still exists.

9 Handling the Inverter

9.1 Removing the SUN2000

NOTICE

Before removing the SUN2000, disconnect both AC and DC connections.

Perform the following operations to remove the SUN2000:

- 1. Disconnect all cables from the SUN2000, including RS485 communications cables, DC input power cables, AC output power cables, and PGND cables.
- 2. Remove the SUN2000 from the mounting bracket.
- 3. Remove the mounting bracket.

9.2 Packing the SUN2000

- If the original packing materials are available, put the SUN2000 inside them and then seal them by using adhesive tape.
- If the original packing materials are not available, put the SUN2000 inside a suitable cardboard box and seal it properly.

9.3 Disposing of the SUN2000

If the SUN2000 service life expires, dispose of it according to the local disposal rules for electrical equipment waste.

10 Technical Specifications

Efficiency

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Peak efficiency	97.1%	98.65%/400 Vac 98.75%/480	98.65%/400 Vac 98.75%/480	98.65%/400 Vac 98.75%/480	98.65%/400 Vac 98.75%/480
		Vac	Vac	Vac	Vac
European efficiency	96.7%	98.4%/400 Vac	98.4%/400 Vac	98.4%/400 Vac	98.4%/400 Vac
		98.45%/480 Vac	98.45%/480 Vac	98.5%/480 Vac	98.5%/480 Vac

Input

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3		
Recommende d maximum DC input power	30,000 W	44,850 W	45,000 W	54,000 W	60,000 W		
Maximum input voltage ^a	800 V	1100 V	1100 V				
Maximum input current (per MPPT)	26 A						
Maximum short-circuit current (per MPPT)	40 A						

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3	
Minimum startup voltage	200 V					
MPP voltage range	200–750 V	200–1000 V				
Full power MPPT voltage range	300–550 V	500–800 V/400 Vac 625–850 V/480 Vac	500-800 Vdc/ (380 Vac, 400 Vac) 625-850 Vdc/400 Vac 625-850 Vdc/480 Vac	520-800 Vdc/ (380 Vac, 400 Vac) 625-850 Vdc/400 Vac 625-850 Vdc/480 Vac	540-800 Vdc/ (380 Vac, 400 Vac) 625-850 Vdc/400 Vac 625-850 Vdc/480 Vac	
Rated input voltage	350 V	600 V (400 Vac) 720 V (480 Vac)	600 V (380 Vac, 400 Vac) 650 V (440 Vac) 720 V (480 Vac)	600 V (380 Vac, 400 Vac) 650 V (440 Vac) 720 V (480 Vac)	600 V (380 Vac, 400 Vac) 650 V (440 Vac) 720 V (480 Vac)	
Maximum number of inputs	8					
Number of MPPTs	4					
			num DC input vo , the SUN2000 m		N2000 can	

Output

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Rated output power	20,000 W	29,900 W	30,000 W	36,000 W	40,000 W
Maximum apparent power	22,000 VA	29,900 VA	33,000 VA ^a	40,000 VA	44,000 VA
Maximum active power (cosφ = 1)	22,000 W	29,900 W	33,000 W ^a	40,000 W	44,000 W

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3	
Rated output voltage	127 Vac (220 Vac), 3W/N +PE	230 Vac (400 Vac), 3W/N +PE	220 Vac (380 Vac), 3W/N +PE	220 Vac (380 Vac), 3W/N +PE	220 Vac (380 Vac), 3W/N +PE	
	230 Vac (400 Vac), 3W/N +PE	277 Vac (480 Vac), 3W+PE	230 Vac (400 Vac), 3W/N +PE	230 Vac (400 Vac), 3W/N +PE	230 Vac (400 Vac), 3W/N +PE	
			254 Vac (440 Vac), 3W/N	254 Vac (440 Vac), 3W+PE	254 Vac (440 Vac), 3W+PE	
			+PE 277 Vac (480 Vac), 3W+PE	277 Vac (480 Vac), 3W+PE	277 Vac (480 Vac), 3W+PE	
Maximum output voltage at long-term operation	See standards a	bout the local po	ower grid.			
Rated output current	52.5 A (220 Vac)	43.2 A (400 Vac)	45.6 A (380 Vac)	54.7 A (380 Vac)	60.8 A (380 Vac)	
	28.9 A (400 Vac)	36.0 A (480 Vac)	43.3 A (400 Vac)	52.0 A (400 Vac)	57.8 A (400 Vac)	
			39.4 A (440 Vac)	47.3 A (440 Vac)	52.5 A (440 Vac)	
			36.1 A (480 Vac)	43.3 A (480 Vac)	48.1 A (480 Vac)	
Maximum output current	58.0 A (220 Vac)	43.2 A (400 Vac)	50.4 A (380 Vac)	61.1 A (380 Vac)	67.2 A (380 Vac)	
	31.9 A (400 Vac)	36.0 A (480 Vac)	47.9 A (400 Vac)	58.0 A (400 Vac)	63.8 A (400 Vac)	
			43.5 A (440 Vac)	52.8 A (440 Vac) (Mexico)	58.0 A (440 Vac) (Mexico)	
			39.9 A (480 Vac)	48.4 A (480 Vac)	53.2 A (480 Vac)	
Output voltage frequency	50 Hz/60 Hz					
Power factor	0.8 leading-0.8 lagging					
Output DC component DCl	< 0.5% of the ra	ated output				

are 30,000 VA and 30,000 W respectively.

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3			
Maximum total harmonic distortion (THD) AC THDi	< 3% under rate	ed conditions. Sir	igle harmonic me	ets the VDE4105	requirements.			
	Note a: Under the Germany VDE-AR-N-4105, Belgium C10/11, and Austria TOR grid codes, the maximum apparent power and the maximum active power ($\cos \Phi$ =1) of the SUN2000-30KTL-M3							

Protection

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3
Overvoltage category	PV II/AC III				
Input DC switch	Supported				
Islanding protection	Supported				
Output overcurrent protection	Supported				
Input reverse connection protection	Supported				
String fault detection	Supported				
DC surge protection	Туре II				
AC surge protection	Туре II				
Insulation resistance detection	Supported				
Residual current monitoring unit (RCMU)	Supported				

Display and Communication

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3					
Display	LED indicator; V	VLAN+app								
RS485	Supported									
Built-in WLAN	Supported									
AC MBUS	Supported									
DC MBUS	Supported	Supported								
AFCI	Supported									
PID	Supported									

General Specifications

Technical Specifications	SUN2000-20K TL-M3	SUN2000-29. 9KTL-M3	SUN2000-30K TL-M3	SUN2000-36K TL-M3	SUN2000-40K TL-M3				
Dimensions (W x H x D)	640 mm x 530 r	mm x 270 mm							
Net Weight	43 kg								
Operating temperature	–25°C to +60°C	(derated when t	he temperature is	s above +45°C)					
Humidity	0%–100%								
Cooling mode	Natural cooling								
Maximum operating altitude	0–4000 m	0–4000 m							
Storage temperature	-40°C to +70°C								
IP rating	IP66								
Тороlоду	Transformerless								

Standards Compliance

Technical	SUN2000-20K	SUN2000-29.	SUN2000-30K	SUN2000-36K	SUN2000-40K			
Specifications	TL-M3	9KTL-M3	TL-M3	TL-M3	TL-M3			
Standards	EN/IEC 62109-1, EN/IEC 62109-2, NB/T 32004-2018							

A Grid Code

D NOTE

The grid codes are subject to change. The listed codes are for reference only.

No.	Grid Code	Description
1	VDE-AR-N-4105	Germany low-voltage (LV) power grid
2	NB/T 32004	China Golden Sun LV power grid
3	UTE C 15-712-1(A)	France mainland power grid
4	UTE C 15-712-1(B)	France island power grid
5	UTE C 15-712-1(C)	France island power grid
6	VDE4110-MV	Germany medium-voltage (MV) power grid
7	G99-England	England 230 V power grid (I > 16 A)
8	G99-Scotland	Scotland 240 V power grid (I > 16 A)
9	CEI0-21	Italy power grid
10	RD1699/661	Spain LV power grid
11	RD1699/661-MV480	Spain MV power grid
12	C10/11	Belgium power grid
13	AS4777	Australia power grid
14	AS4777-ACT	Australia power grid
15	AS4777-NSW-ESS	Australia power grid
16	AS4777-NSW-AG	Australia power grid

No.	Grid Code	Description
17	AS4777-QLD	Australia power grid
18	AS4777-SA	Australia power grid
19	AS4777-VIC	Australia power grid
20	IEC61727	IEC 61727 LV power grid (50 Hz)
21	CEI0-16	Italy power grid
22	CHINA-MV480	China MV standard power grid
23	CHINA-MV	China MV standard power grid
24	TAI-PEA	Thailand grid-tied standard power grid
25	TAI-MEA	Thailand grid-tied standard power grid
26	VDE4110-MV480	Germany MV standard power grid
27	G99-England-MV480	UK 480 V MV grid-tied power grid (I > 16 A)
28	IEC61727-MV480	IEC 61727 MV grid-tied power grid (50 Hz)
29	UTE C 15-712-1-MV480	France island power grid
30	TAI-PEA-MV480	Thailand MV grid-tied power grid (PEA)
31	TAI-MEA-MV480	Thailand MV grid-tied power grid (MEA)
32	C11/C10-MV480	Belgium MV power grid
33	Philippines	Philippines LV power grid
34	Philippines-MV480	Philippines MV power grid
35	NRS-097-2-1	South Africa standard power grid
36	IEC61727-60Hz	IEC 61727 LV grid-tied power grid (60 Hz)
37	IEC61727-60Hz-MV480	IEC 61727 MV grid-tied power grid (60 Hz)
38	CHINA_MV500	China MV standard power grid
39	PO12.3-MV480	Spain MV power grid
40	EN50549-LV	Ireland power grid
41	EN50549-MV480	Ireland MV power grid

No.	Grid Code	Description
42	ABNT NBR 16149	Brazil power grid
43	ABNT NBR 16149-MV480	Brazil MV power grid
44	SA_RPPs	South Africa LV power grid
45	SA_RPPs-MV480	South Africa MV power grid
46	INDIA	India LV power grid
47	INDIA-MV500	India MV power grid
48	G99-TYPEA-LV	UK G99_TypeA_LV power grid
49	G99-TYPEB-LV	UK G99_TypeB_LV power grid
50	G99-TYPEB-HV	UK G99_TypeB_HV power grid
51	G99-TYPEB-HV-MV480	UK G99_TypeB_HV MV power grid
52	G99-TYPEA-HV	UK G99_TypeA_HV power grid
53	EN50549-MV400	Ireland new standard power grid
54	VDE-AR-N4110	Germany 230 V MV power grid
55	VDE-AR-N4110-MV480	Germany MV standard power grid
56	NTS	Spain power grid
57	NTS-MV480	Spain MV power grid
58	CEA	India LV power grid (CEA)
59	CEA-MV480	India MV power grid (CEA)
60	C10/11-MV400	Belgium MV power grid
61	ABNT NBR 16149-LV127	Brazil LV power grid
62	Mexico-LV220	Mexico LV power grid
63	Philippines-LV220-50Hz	Philippines LV power grid (50Hz)
64	Philippines-LV220-60Hz	Philippines LV power grid (60Hz)
65	TAIPOWER-LV220	Taiwan LV power grid

B Device Commissioning

Step 1 Access Device Commissioning screen.




Figure B-1 Method 1: before login (not connected to the Internet)

CANCEL




Figure B-2 Method 2: after login (connected to the Internet)

Step 2 Connect to the solar inverter WLAN and log in to the device commissioning screen as the **installer** user.

NOTICE

- When connecting to the SUN2000 directly from the mobile phone, keep the mobile phone visible within 3 meters of the SUN2000 to ensure the communication quality between the app and SUN2000. The distances are for reference only and may vary with mobile phones and shielding conditions.
- When connecting the SUN2000 to the WLAN over a router, ensure that the mobile phone and SUN2000 are in the WLAN coverage of the router and the SUN2000 is connected to the router.
- The router supports WLAN (IEEE 802.11 b/g/n, 2.4 GHz) and the WLAN signal reaches the SUN2000.
- The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers. Enterprise-level encryption is not supported (for example, public hotspots requiring authentication such as airport WLAN). WEP and WPA TKIP are not recommended because these two encryption modes have serious security defects. If the access fails in WEP mode, log in to the router and change the encryption mode of the router to WPA2 or WPA/WPA2.

SUN2000- XXX-XXX Standby : sunlight detection 4 Energy yield of current day Active powe 0.000(kw) 0.03(kwh) Monthly Energy Yield Total 0.03(kWhi 4.64 (whi R Alarm Quick settings management ~ B Device Monitoring Maintenance {]} t+t Power adjustment Settings

Figure B-3 Quick settings

- Obtain the initial password for connecting to the solar inverter WLAN from the label on the side of the solar inverter.
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- When you access the **Device Commissioning** screen of the SUN2000 for the first time, you need to manually set the login password because the SUN2000 does not have an initial login password.

----End

C Setting Power Adjustment Parameters

Prerequisites

You have logged in to the app as **installer**.

Procedure

- **Step 1** On the home screen, tap **Power Adjustment** and set power parameters as required.
 - SUN2000-XXX Power adjustment Active power control Reactive power control Energy yield of current day 0.000_{two} 0.D0_{ove} Grid-tied point control E Monthly Energy Yield Total 0.00owns 66.65km P Ł Alarm management Quick settings $\overline{}$ B Device Monitoring Maintenance 63 阳 Settings

Figure C-1 Setting Power Adjustment Parameters

----End

D Built-in PID Recovery

NOTICE

Ensure that the inverter ground cable is securely connected. Otherwise, the built-in PID repair function will be affected and electric shocks may occur.

Prerequisites

You have logged in to the app as **installer**.

Procedure

Step 1 On the home screen, choose **Settings** > **Feature Parameters** and set related parameters.




Figure D-1 Setting PID suppression parameters

D NOTE

- Set **PID running mode** to **Repair** (disabled by default).
- Set **Nighttime off-grid repair** to (this parameter is displayed when **Built-in PID running mode** is set to **Repair**).

----End

E Rapid Shutdown

If all PV modules are equipped with optimizers, the PV system can perform a rapid shutdown, reducing the output voltage of the optimizers to below 30 V within 30s. The rapid shutdown is not supported if optimizers are configured for some PV modules.

Triggering methods of rapid shutdown:

- Method 1 (recommended): Turn off the AC switch between the inverter and the power grid.
- Method 2: Turn off the DC switch at the bottom of the inverter.
- Method 3: If the DIN5 port (port 15) of the inverter communications terminal is connected to a rapid shutdown button, press the button to trigger rapid shutdown.



- **Step 1** Check that the AC and DC power supplies to the solar inverter are connected simultaneously, and that the *➡* and *▶* indicators are steady green or blink slowly for more than 3 minutes.
- **Step 2** Turn off the AC switch, set the DC switch at the bottom of the solar inverter to OFF, and wait until all indicators on the solar inverter panel turn off.
- **Step 3** Complete the following operations within 3 minutes:
 - 1. Turn on the AC switch and wait until the \mathbf{r} indicator blinks.
 - 2. Turn off the AC switch and wait until all indicators on the solar inverter panel turn off.
 - 3. Turn on the AC switch and wait until all LED indicators on the inverter panel blink and turn off after about 30s.
- **Step 4** Wait until the three indicators on the inverter panel blink green quickly and then blink red quickly, indicating that the password has been restored.
- **Step 5** Reset the password within 10 minutes. (If no operation is performed within 10 minutes, all parameters of the solar inverter remain the same as those before the reset.)
 - 1. Wait until the r indicator blinks.
 - 2. Obtain the initial WLAN hotspot name (SSID) and initial password (PSW) from the label on the side of the solar inverter to connect to the app.
 - 3. On the login page, set a new login password and log in to the app.
- **Step 6** Set router and management system parameters to implement remote management.

----End

NOTICE

You are advised to reset the password in the morning or at night when the solar irradiance is low.

G Setting Dry Contact Scheduling Parameters

Prerequisites

You have logged in to the app as **installer**.

Procedure

Step 1 On the home screen, choose Settings > Power adjustment and set Dry contact scheduling to _____.

C Power adjustment			<		Dry cont	act so etting		ng	Submi
filtering time	60000 mis	>	· · · · · ·		l active heduling	D	I reactiv	re power	
Power factor	1.000	>		DIU.	recovery		SUIICU		
Reactive power compensation(Q/S)	0.000	>	NO.	011	DI2	DI3	D14	Percen (0.0, 100.0	itage I
Overfrequency derating	a	Ð	1)×. @
PF (U) voltage detection filter time	1.5 s	2							
Apparent power baseline	44.000 kVA	×							
Active power baseline	44.000 KW	5							
Communication disconnection fail-safe	a								
Closed-loop controller SDong	jle/SmartLogger	~ 🔎							
Dry contact scheduling		C							
Dry contact scheduling settings		>							
Limit value for minimum PF of Q-U characteristic curve	0.000	5							
Power percentage for triggering Q-U scheduling	0%	3							
Q-U characteristic curve		>	Note:	٥	Closed	0 0	pen		
Cosd-P/Pn characteristic curve		>	Г			Add			

Figure G-1 Setting dry contact scheduling parameters

----End

Function

If PV modules or cables are not properly connected or damaged, electric arcs may occur, which may cause fire. Huawei SUN2000s provide unique arc detection in compliance with UL 1699B-2018 to ensure the safety of users' lives and property.

This function is enabled by default. The SUN2000 automatically detects arc faults. To disable this function, log in to the FusionSolar app, enter the **Device Commissioning** screen, choose **Settings** > **Feature parameters**, and disable **AFCI**.

Clearing Alarms

The AFCI function involves the **DC arc fault** alarm.


The SUN2000 has the AFCI alarm automatic clearance mechanism. If an alarm is triggered for less than five times within 24 hours, the SUN2000 automatically clears the alarm. If the alarm is triggered for five times or more within 24 hours, the SUN2000 locks for protection. You need to manually clear the alarm on the SUN2000 so that it can work properly.

You can manually clear the alarm as follows:

• Method 1: FusionSolar App

Log in to the FusionSolar app and choose **My** > **Device Commissioning**. On the **Device Commissioning** screen, connect and log in to the SUN2000 that generates the AFCI alarm, tap **Alarm management**, and tap **Clear** on the right of the **DC arc fault** alarm to clear the alarm.

Figure H-1 Alarm management



• Method 2: FusionSolar Smart PV Management System


Log in to the FusionSolar Smart PV Management System using a non-owner account, choose **Intelligent O&M** > **Alarm Management**, select the **DC arc fault** alarm, and click **Clear** to clear the alarm.

Figure H-2 Clearing alarms

Fusic	onSolar										යි Hon	ne Page 🗘 Setting 🖂 Mo	ssage Switch to Dashboar	1 ③ a**** ① Ab
Device Alarm	Diagnosis We	gning												
Plant selection	Select a plant.	Q s	tatus Activated	Alarm Severity Al	Device N	ame	Device Type All		Alarm Type Al		Occurrence Time		m	
Search	Save Reset													
User-define	ed filter											Expo	rt Confirm Cle	ar To Defect
	Plant Name		Device Type	Device Nar	ne Alarm Type	Alarm Name	Alarm ID	Cause ID	Alarm Severity	Status	Local Time	Occurrence Time	Recovery Time	Recovery Suggestion
	XXXXXX		Smart String Inverter	XXXXXXX	Abnormal alam	n DC arc fault	2002	7	Major	Activated	13/11/2019 06:28:10	13/11/2019 05:28:10		Recovery Suggestion
Per page: 10	Total 53 records											K < 9 3 H Page	5 Page/Total 6 Page Go	o page 5 Page Gi

Switch to the owner account with PV plant management rights. On the home page, click the PV plant name to go to the PV plant page, and click **OK** as prompted to clear the alarm.

Figure H-3 Owner confirmation



Smart I-V Curve Diagnosis

For details, see FusionSolar 6.0 Smart PV Management System Smart I-V Curve Diagnosis User Manual.

Acronyms and Abbreviations

Α	
AFCI	arc-fault circuit interrupter
L	
LED	light emitting diode
М	
MBUS	monitoring bus
МРР	maximum power point
МРРТ	maximum power point tracking
Ρ	
PE	protective earthing
PID	potential induced degradation
PV	photovoltaic
R	
RCD	residual current device